



MATTEO GOLD SRL  
Via S. dei Poli, 29  
36022 Cassola (VI) Italy  
Operating office: Via Sarson, 73  
36061 Bassano del Grappa (VI)  
Italy  
TEL: (+39) 424-504381  
E-mail [info@matteogold.com](mailto:info@matteogold.com)

### **MGA003**

It is a liquid detergent at pH 7.5 (neutral) and has good emulsifying properties. It is formulated according to aqueous with high concentration of active.

Material: all metals, especially suitable for gold and silver where a finish is required particularly accurate.

Contaminant: fats, oils.

It is specific for polishing balls both in rotating or in vibrators cradle; it is suitable for all metals, especially suitable for gold and silver where a special finish is required accurate.

It can also be used as a degreaser in ultrasound at the concentration of 2-3% at 50-60 °C.

In ball type use the product causes the particles and fatty substances to be detached from the pieces and kept in suspension without repositioning on the artifacts, allowing to obtain an excellent surface gloss.

If the products have not been previously well degreased, it is advisable to make a short cycle with abundant product (3-5% in water) in order to remove the dirt present on the pieces.

After rinsing, repeat the operation with 1-2% of product for the time needed to achieve the desired brilliance.

Usage:

- Temperature: 40-60 °C
- Concentration: 2-5 %
- Time: 2-5 min.